



This desktop icon launches the software. The Monitor Settings Screen (left) enables the administrator to set the monitoring interval, enable or disable notifications, and more.



### Hardware Definition Screen

This screen allows the administrator to configure Acoustic Network Supervisor to communicate with the Network Control Panel(s) it will monitor. If panels were previously defined in the Acoustic Network Manager Software, they can be imported.



### Notification Settings Screen

This screen allows the administrator to enter the mail server settings, authentication options and message settings, including the subject line, recipient address(es), the priority setting for the email and the facility name. They can also enter vendor information, which inserts the LogiSon Representative's contact information into the email. If the administrator does not elect to copy them on the notifications, they can be contacted directly by the person notified.

Acoustic Network Supervisor runs as a Windows Service, which monitors the LogiSon Acoustic Network to ensure that the system is 100 percent operational 24/7. The administrator can configure it to monitor only the Network Control Panel(s) or all of the system's components. If an issue occurs, the software sends an email so that it can be quickly addressed. Because it monitors externally from the LogiSon Acoustic Network hardware, a hardware failure will not impact its ability to send these alerts.

The administrator defines the intervals at which the system should be checked, from as often as every two minutes up to as long as twenty-four hours. The administrator also defines to whom notification should be sent if an event occurs – for example, to the facility manager, IT personnel and the LogiSon Representative. The administrator can add a unique name (e.g. facility name) to the email, providing a means of identifying individual locations if it is sent to a remote recipient or one who is monitoring several facilities or floors for various tenants. They can also add vendor information to inform the recipient who to contact.

The software can be configured not to send emails in the event of client network outages and can send a start-up message when monitoring resumes. Alive notifications can be enabled to inform recipients that the application is running.

For more information, see the *LogiSon® Acoustic Network Supervisor User Manual*. The application also includes a help file and user guide.

## SPECIFICATIONS

<b>Supported Operating Systems</b>	<ul style="list-style-type: none"> <li>• Windows 10</li> <li>• Windows 8/8.1 Pro</li> <li>• Windows 7</li> <li>• Windows Vista with Service Pack 2 or later</li> <li>• Windows Server 2003 SP2 or later</li> <li>• Windows Server 2008 R2 (not supported on Server Core Role)</li> <li>• Windows Server - Later servers include newer framework versions</li> </ul>
<b>Supported Architectures</b>	<ul style="list-style-type: none"> <li>• X86</li> <li>• X64</li> </ul>
<b>Hardware Requirements</b>	<ul style="list-style-type: none"> <li>• Computer with 1 GHz or faster processor with 1 GB RAM or more</li> <li>• Graphics parts supporting WDDM drivers (Windows Display Driver Model) recommended</li> <li>• Minimum disk space (Microsoft components/Installation):                             <ul style="list-style-type: none"> <li>• X86 – 850 MB</li> <li>• X64 – 2 GB</li> </ul> </li> <li>• Disk space (LogiSon components): 5 MB</li> </ul>
<b>Prerequisites</b>	<ul style="list-style-type: none"> <li>• Windows Installer 3.1 or later</li> <li>• Internet Explorer 6.0 or later</li> <li>• Microsoft .NET Framework 4 or later (included with Windows 8 or later)</li> </ul>